

# HUMAN CANNONBALL

ATARI® GAME PROGRAM™ INSTRUCTIONS



**CX2627**

COMPLETE  
GAME PLAY  
INSTRUCTIONS

ONE AND  
TWO-PLAYER  
GAMES

GAME SELECT  
MATRIX  
Section 5

**TABLE OF CONTENTS**

<b>1. GAME PLAY</b>	<b>1</b>
<b>2. USING THE CONTROLLERS</b>	<b>1</b>
<b>3. CONSOLE CONTROLS</b>	<b>3</b>
<b>4. SCORING</b>	<b>3</b>
<b>5. GAME SELECT MATRIX</b>	<b>4</b>

**NOTE:** Always turn the console power switch off when inserting or removing an ATARI® Game Program™ cartridge. This will protect the electronic components and prolong the life of your ATARI Video Computer System™ game. Manual, Program, and Audiovisual © 1978 ATARI, INC.



## 1. GAME PLAY

Careful now, the HUMAN CANNONBALL is counting on you to make your calculations accurately. Otherwise he'll end up flat as a pancake and you'll end up with 0 points or a miss to show for it!


The objective of this game is to shoot the man out of the cannon and into the water tower. To accomplish this, you must consider the following variables:

- The angle of the cannon (establishes the line or arc of trajectory the man follows after being shot from the cannon).

- The speed (MPH) at which the man travels after being shot from the cannon.
- The distance between the cannon and the water tower.

These variables are set by you and/or the computer, depending on the game you're playing. In some games, the cannon position remains fixed throughout the game. There are 8 game variations in all. Each game variation contains a one- and two-player version. (See the **GAME SELECT MATRIX**.)

## 2. USING THE CONTROLLERS




Use your Joystick Controllers with this ATARI® Game Program™ cartridge. Be sure the Joystick Controller cables are firmly plugged into the **CONTROLLER** jacks at the back of your ATARI Video Computer System™ game. For one-player games, use the Joystick Controller


plugged into the **LEFT CONTROLLER** jack. Hold the Joystick with the red button to your upper left, toward the television screen. See *Section 3 of your owner's manual* for further details.

### SETTING GAME VARIABLES:

Use your Joystick Controller to adjust and set the game variables. Press the red button on your controller to shoot the man out of the cannon.


In games where the cannon angle can be adjusted, the Joystick works as follows:




The minimum cannon angle for all games is **20** degrees. The maximum angle is **80** degrees. The cannon angle is shown near the top, middle of the screen. (Example:  = 26.) The cannon itself only approximately shows the angle.

In games where the speed (MPH) can be adjusted, the Joystick works as follows:


The maximum speed for all games is **45** MPH. It is possible, (but not practical for scoring) to adjust the speed down to **0** MPH. The speed is displayed near the top of the screen, just above the cannon angle. (Example: MPH = 38.)



In games where the cannon's position can be adjusted, the Joystick works as follows:



In **Games 1, 2, 3, and 4** the water tower can be moved back and forth **after** the man is shot from the cannon. In these games, the Joystick works as follows:



**Games 5, 6, 7, and 8** have a moving "window" which is positioned in front of the water tower on the screen. Time your shot so that the man travels through the window en route to the water tower.

The water tower cannot be moved in **Games 5, 6, 7, and 8**.




### 3. CONSOLE CONTROLS

#### GAME SELECT AND GAME RESET

To select a game, press the **game select** switch. The game number appears at the upper left corner of the screen. A 1 is displayed at the upper right corner of the screen for a one-player game. A 2 is displayed (upper right corner) for a two-player game.

To begin a game, press **game reset**.



### 4. SCORING

In one-player games, you score one point for each successful shot. The computer records 1 point against you for each miss. Your score is

#### DIFFICULTY SWITCHES

It is easier for the beginning player to start with the difficulty switch in the **b** position. In the **b** position, the water tower is twice as wide as it is when the switch is in the **a** position.

Use the **left difficulty switch** for one-player games.


#### TV TYPE SWITCH

Set this switch to **color** if you have a color television set. Set it to **b-w** if you are playing the game in black and white.

shown at the top, left side of the screen. The number of misses is displayed at the top, right side of the screen.

Number of Hits  
Left Player's  
Score

Number of Misses  
Right Player's  
Score



The game ends after 7 successful "shots" or 7 misses.

In two-player games, each player scores 1 point for a successful "shot." Misses have no effect on scoring. The first player to score 7 points is the winner.

**Note:** After a player scores 7 points, the second player gets one more turn before the game ends.

The left player's score is shown at the top, left side of the screen; the right player's score is shown at the top right side of the screen.

### 5. GAME SELECT MATRIX

Game Number	1	2	3	4	5	6	7	8
Cannon Position	Fixed	Fixed	Chosen by Player	Chosen by Player	Fixed	Fixed	Chosen by Player	Chosen by Player
Speed (MPH)	Chosen at Random by Computer	Chosen at Random by Computer	Chosen by Player	Chosen by Player	Chosen at Random by Computer	Chosen at Random by Computer	Chosen by Player	Chosen by Player
Cannon Angle	Chosen at Random by Computer	Chosen at Random by Computer	Chosen by Player	Chosen by Player	Chosen at Random by Computer	Chosen at Random by Computer	Chosen by Player	Chosen by Player
Movable Tower	Chosen at Random by Computer	Chosen at Random by Computer	Chosen at Random by Computer	Chosen at Random by Computer	Fixed	Fixed	Fixed	Fixed
Moving Window	Fixed	Fixed	Fixed	Fixed	Chosen at Random by Computer	Chosen at Random by Computer	Chosen at Random by Computer	Chosen at Random by Computer

 Chosen at Random by Computer

 Fixed

 Chosen by Player



## GAME PROGRAM™ CARTRIDGE LIMITED NINETY DAY WARRANTY

ATARI, INC. ("Atari") warrants to the original consumer purchaser that your ATARI® Game Program cartridge is free from any defects in material or workmanship for a period of ninety days from the date of purchase. If any such defect is discovered within the warranty period, Atari's sole obligation will be to replace the cartridge free of charge on receipt of the cartridge (charges prepaid, if mailed or shipped) with proof of date of purchase at either the retail store where the cartridge was purchased or at one of the ATARI Regional Service Centers listed below:

Atari, Inc.  
1312 Crossman Ave.  
Sunnyvale, CA 94086

Atari, Inc.  
5400 Newport Dr.  
Suite 1  
Rolling Meadows, IL 60008

Atari, Inc.  
43 Belmont Dr.  
Somerset, NJ 08873

Atari, Inc.  
2109 East Division St.  
Arlington, TX 76001

This warranty shall not apply if the cartridge (i) has been misused or shows signs of excessive wear; (ii) has been damaged by being used with any products not supplied by ATARI, or (iii) has been damaged by being serviced or modified by anyone other than an ATARI Regional Service Center.

ANY APPLICABLE IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS, ARE HEREBY LIMITED TO NINETY DAYS FROM THE DATE OF PURCHASE. CONSEQUENTIAL OR INCIDENTAL DAMAGES RESULTING FROM A BREACH OF ANY APPLICABLE EXPRESS OR IMPLIED WARRANTIES ARE HEREBY EXCLUDED.

Some states do not allow limitations on how long an implied warranty lasts or do not allow the exclusion or limitations of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.



A Warner Communications Company 

ATARI, INC., Consumer Division  
P.O. Box 427, Sunnyvale, CA 94086